




Case Analysis
Flap Design
Vertical Cuts
Flap Release
Flap Closure

Improper Mix
Over /Under Liquid - Powder Ratio
Non-Compliance With The Working
Time

Blocking The Syringe Gunning
Working By Small Increments
Shaping The Material Before
Compression
Improper Material Compression
Socket Preservation Protocol
Slow Lift Protocol
Vertical Augmentation Protocol
During Sulfuring

Temperature





"Dünya için en büyük ihtiyaç olan şey
her şey için en büyük ihtiyaç olan şeydir:
Çalışkanlık!"



K. Atatürk

